








Garden Luxury Series GL4 Outdoor Sauna
80D" x 59W" x 86H"


















Note: Please read manual before construction














Garden Luxury Series GL4 Outdoor
Sauna 80D" x 59W" x 85H"















VS2T FI1	 	Base frame	1.7"x3.5"x78"	2
VS2T FI2	 	Base frame	1.7"x3.5"x53.7"	8
VS2T W1	 	Wall log	1.57"x4.6"x78"	18
VS2T W1.1	 	Wall log	1.57"x4.3"x78"	1
VS2T W1.2	 	Wall log	1.57"x4.3"x78"	1
VS2T W2	 	Wall log	1.57"x4.6"x63.4"	18
VS2T W3	 	Wall log	1.57"x4.6"x54"	17
VS2T W3.1	 	Wall log	57"x4.3"x54"	1





VS2T W3.2		Wall log	1.57"x3.81"x54"	1
VS2T W3.3		Wall log	1.57"x3.93"x54"	1
VS2T Cp		Corner post	1.7"x1.7"x75"	2
VS2T sp		Support	1.7"x1.7"x70.8"	4
VS2T WE		Window element	27.07"x75"	1
VS2T DE		Door element	27.07"x75"	1
VS2T Wex		Wind slat for window element (plywood)	0.35"x1.53"x74.25" (plywood)	1


VS2T Rb		Roof board	1.57"x4.6"x76.37"	12
VS2T Rbc		Roof board (cutted)	1.57"x2.52"x76.37"	1
VS2T Fib		Floor board	1"x4.6"x58.9"	11
VS2T Fib2		Floor board (vent hole)	1"x4.6"x58.9"	1
VS2T Fib3		Floor board (cutted)	1"x2.7"x58.9"	1
VS2T Bs1		Bench support	1.7"x1.7"x11.2"	2
VS2T Bs2		Bench support	1.7"x2.7"x20.78"	2

VS2T B1		Bench 1	12.7"x53.6"	1
VS2T B2		Bench 2	23.6"x53.6"	1
VS2T Br		Backrest	15.7"x53.6"	1
VS2T Cs1		Cover slat	0.7"x4.65"x58.6"	1
VS2T Cs2		Cover slat	0.7"x4.65"x78.7"	2
VS2T Cs3		Cover slat	0.7"x4.65"x57.16"	1
VS2T Cs4		Cover slat	0.7"x3.93"x58.6"	1
VS2T Cs5		Cover slat	0.7"x3.93"x78.7"	2

VS2T Cs6		Cover slat (corner cut)	0.7"x3.7"x80.4"	2
VS2T Cs7		Cover slat	0.7"x3.7"x49.7"	1
VS2T Cs8		Cover slat	0.7"x3.7"x76.4"	5
VS2T Cs9		Cover slat	0.7"x2.44"x76.4"	1
VS2T Cs10		Cover slat	0.7"x2.83"x76.4"	1
VS2T Cs11		Cover slat	0.7"x1.77"x73.3"	1
VS2T Cs12		Cover slat	0.7"x1.77"x53.4"	1
VS2T Tr		Terrace	14.5"x55.4"	1


VS2T Hc1		Heater cover board (side)	0.7"x3.7"x21.65"	4
VS2T Hc2		Hetaer cover board (front)	0.7"x3.7"x23.62"	2
VS2T Hc3		Heater cover frame	1.1"x1.7"x7.87"	4
		Metal roofing sheet (for back wall)	53.9"	1
		Metal roofin sheet (for side wall)	78.7"	1
		Metal roofing sheet (for side wall)	78.7"	1
		Metal roofing sheet (for front wall)	59"	1
		Rubber roof cover	1x8m	1

		Silicon gun		1
		Bitumen sealant		1
		Vent cover floor		1
		Vent cover (wooden, inside)		1
		Vent cover (metal, outside)		1
		Door handle		1
		Cap for door&window frame screw holes		14
		Hitting block	12"	2




6.3" screws

152



3.5" screws

31



3.15" screws

18



2.7" screws

278



2.4" screws

4



2" screws

4



1.77" screws

48



1.6" screws (black)

160



1.2" screws

6



2" screws (round head)

6



1" screws (round head)

7



1" screws (roofing screw)


26





2.2" bolt (door handle)

2


Connect the base frame according to drawings. Make sure the diagonals are equal ($X=Y$). Connect the base frame using 3.5" screws and 3.15" screws.





FI 1	1.7"x3.5"x78"	2
FI 2	1.7"x3.5"x53.7"	2
3.5" screws		8




FI 2	1.7"x3.5"x53.7"	6
3.15" screws		18
3.5" screws		16



Start by placing the first row of wall logs on the Base frame. Make sure the outside edge of the wall logs aligns perfectly with the outside edge of the base frame. Use 6.3" screws to secure these wall logs to the base frame. To prevent the logs from splitting, pre-drill your holes with a 6mm drill bit before inserting the screws.




W1	1.57"x4.6"x78"	1
W2	1.57"x4.6"x63.4"	1
W3	1.57"x4.6"x54"	1
6.3" screws		8



Place the second row of wall logs directly on top of the first. Use a hitting block and rubber mallet to gently tap and set them into place. Secure this row to the first using 6.3" screws, pre-drill holes for these screws to prevent the logs from splitting.

Next, install the corner posts in the inner corners. Make sure to leave a 1.77" gap between the bottom of the corner post and the base frame. Use 2.7" screws to secure the corner posts between the wall logs, remembering to pre-drill.





W1	1.57"x4.6"x78"	1
W2	1.57"x4.6"x63.4"	1
W3	1.57"x4.6"x54"	1
Cp	1.7"x1.72"x75"	2
2.7" screws		12
6.3" screws		8

Plumb the corner posts and attach temporary supports with 2.7" screws to ensure they stay.




Drill the pilot holes for the screws.

sp	1.7"x1.7"x70.8"	4
2.7" screws		8




W1	1.57"x4.6"x78"	3
W2	1.57"x4.6"x63.4"	3
W3	1.57"x4.6"x54"	3
2.7" screws		24
6.3" screws		24


Fix the detail Wex to the window element, using 1.2" screws.




Wex	0.35"x1.53"x74.25"	1
1.2" screws		6




Once you've fixed the five rows of wall logs, it's time to install the window and door elements. Make sure the door element aligns with W2 from the outside. The window elements (Wex2) should fit securely into the milled groove, W1. Use 2.7" screws for all these locations.




Connect the Door and Window from inside using 2" round-head screws. From the bottom use 2.7" screws to connect window element to the base frame. The holes are already pre-drilled.



Window	27.07"x74.25"	1
Door	27.07"x75"	1
2.7" screws		12
2" screws	round head	6





Continue installing the wall logs. Use 6.3" screws to attach the logs to each other and 2.7" screws to fix all logs to the corner posts. Pre-drill holes for all screws to prevent the wall logs from splitting.



2.7" screws


W1	1.57"x4.6"x78"	13
W2	1.57"x4.6"x63.4"	13
W3	1.57"x4.6"x54"	12
W3.1	1.57"x4.3"x54"	1
2.7" screws		130
6.2" screws		104







W3.2	1.57"x3.81"x54"	1
2.7" screws		6

Secure the final row of wall logs using 6.3" screws. Attach detail W3.3 with 3.5" screws.






W1.1	1.57"x4.3"x78"	1
W1.2	1.57"x4.3"x78"	1
W3.3	1.57"x3.93"x54"	1
3.5" screws		4
6.3" screws		8


Use 2.7" screws to connect roof boards.



Begin installing the floor boards from the door side. Make sure to leave a 3mm gap between the floor boards and the walls on all sides. Use 1.77" screws to secure the floor boards, pre-drill the holes for the screws to prevent any splitting.



1.77" screws






Flb	1"x4.6"x58.9"	11
Flb2	1"x4.6"x58.9"	1
Flb3	1"x2.7"x58.9"	1
1.77" screws		48
2" screws		4

Measure the required distance, then fix the upper and lower supports to the walls. The marked line on the upper bench supports should align with the corner posts. Use 2.7" screws for this step.





Bs1	1.7x1.7x11.2	2
Bs2	1.7x2.7x20.78	2
2.7" screws		10



Cut the ventilation hole in the back wall with a diameter of 3.95" using a hole saw or a jigsaw.

First, lift the benches and place them onto their supports. Make sure to leave a 5mm gap between the benches and the side walls. Secure the benches to the supports by screwing up through the bench's bottom frame using 2.7" screws. It's important not to fully tighten these screws yet. For the backrest, attach it at a comfortable height, approximately 4.7" up from the bench. Use 3.15" screws for this connection.




Bottom view


Bench 1	12.3x53.6	1
Bench 2	23.6x53.6	1
Backrest	15.7x53.6	1
2.7"screws		8
3.15"screws		4

Position the terrace in place before starting the cover slat assembly. Begin the cover slat assembly with Cs2 and Cs5. Ensure Cs2 is flush with the bottom of the floor supports. Cs5 must be flush with the upper edges of side walls. Fasten both with 1.7" black screws. Next, proceed to fix the Cs1 and Cs4 cover slats.


Terrace	14.5"x55.4"	1
Cs1	0.7"x4.65"x58.6"	1
Cs2	0.7"x4.65"x78.7"	2
Cs4	0.7"x3.93"x58.6"	1
Cs5	0.7"x3.93"x78.7"	2
1.6" screws	(black)	48




Continue cover slats assembly on the back side. When you're working with Cs6, make sure its corner cutout is flush with the roof boards. If you find it's a bit too high, simply use a saw to cut it down to the correct dimension.



Drill the pilot holes for the screws





Cs3	0.7"x4.65"x57.16"	1
Cs6	0.7"x3.7"x80.4"	2
Cs7	0.7"x3.7"x49.7"	1
1.6" screws	(black)	34





Cut this boards to the right length and fasten with 1.6" screws.

Cs8	0.7"x3.7"x76.4"	2
Cs9	0.7"x2.44"x76.4"	1
1.6" screws	(black)	15



Cut this boards to the right length and fasten with 1.6" screws.

Cs8	0.7"x3.7"x76.4"	2
Cs10	0.7"x2.83"x76.4"	1
1.6" screws	(black)	15




Drill the pilot holes
for the screws


Cs11	0.7"x1.77"x73.3"	1
Cs12	0.7"x1.77"x53.4"	1
1.6" screws	(black)	10

Attach the back wall roofing sheet
to the roof boards using 1"screws.

**1" screws
(round head)**




**Metal roofing sheet
(Back wall)**




Metal roofing sheet	53.9"	1
1" screws	(round head)	6



Take your roof material and cut three sheets, each approximately 63" long. Begin the assembly from the back side of the sauna. Place the first sheet of roof covering onto the roof. Carefully fold it up from the side walls. Then, trim any excess rubber from the top of the walls. Attach the second sheet of roof covering in the same manner.




Cutting the last sheet of roof covering




Now, place the last sheet of roof covering onto the roof. Carefully fold the material up from the side wall corners and around the front beam corner. Once it's neatly in place, trim off any excess rubber.





Hc1	0.7"x3.7"x21.65"	4
Hc2	0.7"x3.7"x23.62"	2
Hc3	1.1"x1.7"x7.87"	4
1.6" screws	black	24


ATTENTION!
HEATER GUARD MAY NOT
MEET THE SAFETY DISTANCES
OF ALL HEATERS AND SHOULD
NOT BE USED IF THE HEATER
DOES NOT FIT



Connect the heater cover
 to the wall with 2.4" screws.
 Perform this step only after
 heater is installed.

Heater cover	1
2.4" screws	4

Door handle assembly






ADJUSTING THE SAUNA DOOR

6A. If needed then the position of the glass can be adjusted by removing the hinge cover from the inside.

6B. Loosen the hinge bolts, adjust the glass to the desired position, then tighten the bolts to secure it.

7. The door kit includes a roller latch and if it is necessary to adjust this during installation, then this can be done by adjusting the latch's bolt so it works smoothly but the door can still remain tightly shut.



Garden Luxury Series GL4 Outdoor Sauna

80D" x 59W" x 86H"

Product installation instructions

- When building a wooden product, its high-quality and precise installation is important, so that the wood is protected and its durability is guaranteed.
- As an organic material, wood needs regular maintenance to preserve its properties for longer.
- Handle product details with care during installation.
- Do not scratch the surface of the wood or let the boards rub against each other.
- Thermally treated wood has a characteristic smell that diminishes over time, but does not completely disappear. In a sauna, the smell weakens faster if it is heated for a long time and aired at the same time. The smell is softened by treating the wood with a suitable wood oil or wood care product. Do not wash untreated thermal wood with water, as this will make the smell stronger.
- Read the installation and user manuals of the product and the installation manuals of all the devices used.
- Make sure that the wooden materials are not constantly exposed to water during and after installation. The base surface of the product must be suitable for light construction outerbuilding, with sufficient bearing capacity and sufficiently stable.
- The product must be installed on a pre-made foundation that is level - this ensures trouble-free operation of doors and windows.
- Immediately after installing the product, check the mobility of the windows and doors, if necessary, adjust and lubricate with suitable lubricants.
 - In the future, regularly check the condition of window and door hinges and locks. If necessary, tighten the hinge bolts, adjust the locking and use suitable lubricants.
- All electrical and plumbing work must be carried out by a qualified specialist (including the installation of an electric heater).
- It is mandatory to treat the wooden parts of the product with a wood preservative immediately after setting up the product (see also point 2 of the Warranty conditions) in order to protect the wood from moisture and other circumstances affecting the wood. Special wood protection products for wooden products (including saunas) are available in a well-stocked hardware store. The manufacturer is not responsible for products that are damaged due to non-treatment with a wood preservative or incorrect installation!
 - If the product comes with wooden skirting boards that can be attached to the edges of the roof, they must be finished and installed immediately after the product is erected.
- Protective products improve the wood's resistance to dirt and moisture, make it easier to clean and make the appearance more beautiful. We recommend finishing the product with a wood preservative at least once a year or more often, it significantly extends the life of the product.
- A few times a year or as needed, check and adjust the condition of the product's wicks, tighten or loosen if necessary.

Garden Luxury Series GL4 Outdoor Sauna

80D" x 59W" x 86H""

Additional advice on SAUNA INSTALLATION AND MAINTENANCE

Installation of the heater and heater stones

- Make sure that the manufacturer's instructions are followed when installing the heater and chimney.
- Wash heater stones before placing them on the heater to remove stone dust and any manufacturing chemicals.
- Install the heater stones according to the manufacturer's instructions and make sure that the heating elements are not visible, as pouring water directly on them can shorten their life.
- Do not use the sauna during the first heating.
- The first heating must take place under supervision for two hours to a temperature of about 100°C. The sauna must be well ventilated both during and after heating. Due to the heat, the wood absorbs the finishing materials and a protective layer is formed from them.

During use

- If there is a water tank, fill the water tank with water. If the water in the water tank boils, some of it can be drained out for washing and replaced by cold water in the tank.
- For a wood heater, use dry firewood up to 30 cm long.
- When making a fire, keep the ash door slightly open - air can move better. When the wood has caught fire, close the ash pit.
- Throw steam water only on the heater, not on the walls or the sauna bench.
- Do not wear swimwear in the sauna, because the water dripping from them will damage the sauna bench.
- To keep the sauna bench fresh, we recommend using seating pads - this way it is more comfortable to sit on a hot bench.
- Check the heater stones as they can crack over time. Stones can be replaced or added if necessary.

After each use

- Wipe the sauna bench with a clean damp cloth. Do not use running water to clean the bench and make sure that there are no puddles on the wooden surface.
- Use suitable cleaning products for cleaning the sauna bench and other wooden parts.
- After cleaning the sauna, let the surfaces dry and ensure that the room is well ventilated. We recommend leaving the heater on for at least half an hour, with the vent open and the door and windows closed at the same time.

At least once a year

- Treat the wooden surfaces of the sauna with a suitable product. If the sauna is used often, the surfaces should be treated more often.
- Clean all seating surfaces, walls and ceilings with a soft brush or cloth and a special cleaning agent, following the instructions provided.
- For heavier stains and dirt, first clean the sauna bench with fine sandpaper and then treat the sanded surface with a wood preservative.
- Do not use paints or varnishes, because the wood must be able to breathe.
- Avoid using cleaning products unsuitable for the sauna. For example, disinfectants bleach wood and can damage its surface.
- Check the mounting of benches and supports. If necessary, overtighten the screws - they can loosen over time as the wood changes with heat and moisture.

Garden Luxury Series GL4 Outdoor Sauna

80D" x 59W" x 86H"

What to avoid?

- Do not dry textile items in the sauna, as this can be a fire hazard. Excessive moisture can also damage the surface of the wood.
- Avoid heating the sauna above the maximum temperature specified by the heater manufacturer. Excessive heat can create a fire hazard and the wood can also start to warp.
- Do not use a pressure washer or running water to clean the sauna, because excessive moisture can permanently damage the structure and surface of the wood.

How does the wood used in the sauna change?

- Wood is a natural material and changes in temperature can cause its surface to crack or warp.
- Given the extreme temperature and humidity fluctuations that occur in saunas over a short period of time, such changes in wood are normal.
- The risk of deformation depends on the material and its intensity of use, and the changes are more visible in the case of wider boards.
- Wood materials in the area most exposed to hot steam may darken over time.